

COMPREHENSIVE SPREADER CONVERSION

The Andersons Model 2000, 2000 SR, & LCO-1000	Agri Fab Rotary	Earthway Rotary	Earthway Drop	Lesco Rotary (numbers)	Lesco Rotary (letters)	Prizelawn BF1 / CBR / III / CBR IV	Prizelawn LF II	Scotts Rotary (Consumer)	Scotts Drop (Consumer)	Scotts EasyGreen (Consumer)	Scotts RBA Pro Rotary	Spyker Rotary
E 1/2	--	6 1/2	6 1/2	5	--	--	--	**	2	--	D	3.1
F	--	7	7	--	--	D	--	**	2 1/2	22	D 1/2	3.2
F 1/2	--	8	8	6	B	--	--	**	3	23	E	3.4
G	--	9	9	7	B 1/2	E	2	**	3 1/2	--	E 1/2	3.5
G 1/2	2	9 1/2	9 1/2	--	--	--	--	2	4	24	F	3.6
H	--	10	10	8	C	F	--	2 1/4	4 1/4	--	F 1/2	3.7
H 1/2	2 1/2	10 1/2	10 1/2	--	--	--	--	2 1/2	4 1/2	24 1/2	G	3.9
I	--	11	11	9	C 1/2	G	2 1/2	2 3/4	4 3/4	--	G 1/2	4
I 1/2	3	11 1/2	11 1/2	--	--	--	--	3	5	--	H	4.1
J	3 1/2	12	12	10	D	H	--	3 1/2	5 1/2	25	H 1/2	4.3
J 1/2	--	12 1/2	12 1/2	--	--	--	--	3 3/4	6	--	I	4.5
K	4	13	13	11	D 1/2	I	3	4	6 1/4	25 1/2	I 1/2	4.7
K 1/2	4 1/2	13 1/2	13 1/2	--	--	--	--	4 1/2	6 1/2	--	J	4.9
L	5	14	14	--	--	J	3 1/2	5	7	26	J 1/2	5
L 1/2	5 1/2	14 1/2	14 1/2	12	E	--	--	5 1/2	7 1/2	--	K	5.2
M	--	15	15	--	--	K	4	5 3/4	7 3/4	--	K 1/2	5.4
M 1/2	6	15 1/2	15 1/2	13	E 1/2	--	--	6	8	--	L	5.5
N	6 1/2	16	16	--	--	L	4 1/2	6 1/2	8 1/2	27	L 1/2	5.7
N 1/2	--	16 1/2	16 1/2	14	F	--	--	6 3/4	8 3/4	--	M	5.9
O	7	17	17	--	--	M	5	7	9	--	M 1/2	6
O 1/2	--	17 1/2	17 1/2	--	--	--	--	7 1/4	9 1/2	--	N	6.2
P	--	18	18	15	F 1/2	N	5 1/2	7 3/4	9 3/4	28	N 1/2	6.4
P 1/2	8	18 1/2	18 1/2	16	G	--	--	8	10	--	O	6.5
Q	8 1/2	19	19	--	--	O	6	8 1/2	10 1/2	--	O 1/2	6.7
Q 1/2	--	--	--	--	--	--	--	8 3/4	11	--	P	6.9
R	9	20	20	17	G 1/2	P	--	9	11 1/2	29	P 1/2	7
R 1/2	--	21	21	--	--	--	6 1/2	9 1/2	12	--	Q	7.2
S	10	22	22	--	--	Q	--	10	12 1/2	--	Q 1/2	7.4
S 1/2	--	--	--	18	H	--	--	10 1/2	13	--	R	7.5
T	11	23	23	--	--	R	7	11	13 1/2	30	R 1/2	7.7
T 1/2	--	--	--	--	--	--	--	11 1/2	14	--	5	7.9
U	12	24	24	19	H 1/2	S	--	12	14 1/2	--	S 1/2	8
U 1/2	--	--	--	--	--	T	7 1/2	12 1/2	15	--	T	8.3
V	13	25	25	--	--	U	--	13	15 1/2	31	T 1/2	8.5
V 1/2	--	--	--	--	--	--	--	13 1/2	16	--	U	8.7
W	14	26	26	20	I	V	--	14	16 1/2	--	U 1/2	8.9
W 1/2	--	--	--	--	--	W	8	14 1/2	17	--	V	9
X	15	27	27	21	J 1/2	X	--	15	17 1/2	32	V 1/2	9.3
X 1/2	--	--	--	--	--	--	--	--	18	--	W	9.5.2
Y	--	28	28	22	J	Y	8 1/2	--	--	--	W 1/2	9.7
Y 1/2	--	29	29	23	J 1/2	--	--	--	--	--	--	9.9
Z	--	30	30	--	--	Z	9	--	--	--	X 1/2	10

DISCLAIMER: These spreader settings were established using standard equipment available from the spreader manufacturer at swath widths and speeds typically used within the industry. Many variables such as walking speed, terrain, particle size, density, and spreader condition can affect these settings. Spreader settings are intended as a guide and unit calibration should still be performed to ensure proper application rates. They are not intended to replace calibration.

AndersonsHomeandGarden.com
STILL NEED HELP WITH SPREADER SETTINGS?
 Give us a call 877-474-8262